

ZIPPERTUBING PRODUCTS WITH NATIONAL STOCK NUMBERS

NSN	ZIPPERTUBING P/N	SIZE (I.D.)	OLD ZT P/N (pre-1993)	COMMENTS	REPLACEMENT
5120-01-019-4115	SLR		SLR	R-Track Ring Slider	USE "ZTZ-SP"
5325-01-019-2881	NONE		SLZ	OBSOLETE	
5120-01-343-9112	ZTZ-SP		ZTZ-SP	Z-Track Plier Tool	
5210-01-159-6957	ZTZ-SP		ZTZ-SP	Z-Track Plier Tool	
5970-00-851-4288	ZT99-16-005-3/8	3/8	ZTZ-0375-GP-20-B		
5970-01-201-4142	ZT99-16-052-3/8	3/8	ZTZ-0375-63-20-B		
5970-00-080-1422	N/A	3/8	ZTR-0375-63-20-C-OL	OBSOLETE	NONE
5970-00-809-1230	N/A	3/8	ZTZ-0375-63-40-B	OBSOLETE	NONE
5970-00-838-4544	N/A	3/8	ZTZ-0375-74-20-B	OBSOLETE	ZT99-16-039-3/8 (PFR-18)
5970-00-970-3709	N/A	3/8	ZTZ-0375-74-20-C	OBSOLETE	NONE
5970-01-157-4335	ZT99-16-039-3/8	3/8	ZTZ-0375-PFR-20-B	PFR-18	
5970-01-114-1975	ZT94-11-004-1/2	1/2	ZTZ-0500-AP-20-B		
5970-00-997-8668	ZT99-16-005-1/2	1/2	ZTZ-0500-GP-20-B		
5970-00-181-0645	ZT99-16-002-1/2	1/2	ZTR-0500-GP-20-B		
5970-00-725-8685	ZT99-16-052-1/2	1/2	ZTZ-0500-63-20-B		
5970-00-080-1424	ZT99-16-049-1/2	1/2	ZTR-0500-63-20-B		
5970-00-442-2028	N/A	1/2	ZTZ-0500-63-20-C	OBSOLETE	NONE
5970-01-250-0209	N/A	1/2	ZTZ-0500-63-20-Y	OBSOLETE	NONE
5970-00-809-1233	N/A	1/2	ZTZ-0500-63-40-B	OBSOLETE	NONE
5970-01-013-6221	N/A	1/2	ZTR-0500-63-40-C	OBSOLETE	NONE
5970-01-014-7546	N/A	1/2	ZTZ-0500-63-40-C	OBSOLETE	NONE
5970-01-088-3908	N/A	1/2	ZTZ-0500-74-20-B	OBSOLETE	ZT99-16-039-1/2 (PFR-18)
5970-01-330-0640	N/A	1/2	ZTR-0500-74-20-B	OBSOLETE	NONE
5970-00-970-3708	N/A	1/2	ZTZ-0500-74-20-C	OBSOLETE	NONE
5970-01-187-5282	ZT99-16-039-1/2	1/2	ZTZ-0500-PFR-20-B	PFR-18	
5970-00-224-8316	N/A	1/2	ZTZ-0500-SHN3-B	OBSOLETE	ZT02-17-022-1/2 (SH1+VNH-23)
5970-01-124-3784	N/A	1/2	ZTZ-0500-SHX2-ES-B	OBSOLETE	NONE
5970-01-115-7793	ZT97-17-066-1/2	1/2	ZTZ-0500-SHX4-63-20-B		
5970-00-485-5516	N/A	1/2	ZTZ-0500-SHX4-74-20-B	OBSOLETE	ZT97-17-092-1/2 (PFR-18)
5970-01-267-1848	N/A	1/2	ZTZ-0500-SHX4-74-20-B-LTT	OBSOLETE	ZT97-17-092-1/2 (PFR-18)
5970-01-261-0037	N/A	1/2	ZTZ-0500-SH3-PFR-20-B	OBSOLETE	ZT02-17-014-1/2 (SH1+PFR-18)
5970-01-097-2050	ZT99-16-160-1/2	1/2	ZTZ-0500-ALSR-FEP-S		
5970-00-995-0876	ZT99-16-005-5/8	5/8	ZTZ-0625-GP-20-B		

5970-01-310-8842	ZT99-16-044-5/8	5/8	ZTZ-0625-GP-20-B-OL		
5970-00-725-8684	ZT99-16-052-5/8	5/8	ZTZ-0625-63-20-B		
5970-00-650-0568	N/A	5/8	ZTZ-0625-63-20-C	OBSOLETE	NONE
5970-01-013-6226	N/A	5/8	ZTZ-0625-63-40-C	OBSOLETE	NONE
5970-00-451-4944	N/A	5/8	ZTR-0625-63-40-C	OBSOLETE	NONE
5070-01-298-5305	N/A	5/8	ZTZ-0625-74-20-B-OL	OBSOLETE	ZT99-16-078-5/8 (PFR-18)
5970-00-926-0207	N/A	5/8	ZTZ-0625-74-20-B	OBSOLETE	ZT99-16-039-5/8 (PFR-18)
5970-01-147-6119	N/A	5/8	ZTZ-0625-74-20-C	OBSOLETE	NONE
5970-01-044-8018	N/A	5/8	ZTZ-0625-SHN3-B	OBSOLETE	ZT02-17-022-5/8 (SH1+VNH-23)
5970-01-224-0059	N/A	5/8	ZTR-0625-SHN3-B	OBSOLETE	TBD (SH1+VNH-23)
5970-01-145-1501	ZT97-17-066-5/8	5/8	ZTZ-0625-SHX4-63-20-B		
5970-01-263-8409	N/A	5/8	ZTZ-0625-SH3-PFR-20-B	OBSOLETE	ZT02-17-014-5/8 (SH1+PFR-18)
5970-01-053-2444	ZT94-11-004-3/4	3/4	ZTZ-0750-AP-20-B		
5970-01-339-9758	ZT99-16-044-3/4	3/4	ZTZ-0750-GP-20-B-OL		
5970-00-233-9299	ZT99-16-003-3/4	3/4	ZTS-0750-GP-20-B		
5970-01-200-7995	ZT99-16-052-3/4	3/4	ZTZ-0750-63-20-B		
5970-00-822-6255	N/A	3/4	ZTZ-0750-63-20-C	OBSOLETE	NONE
5970-00-451-4943	N/A	3/4	ZTR-0750-63-40-C	OBSOLETE	NONE
5970-01-013-6216	N/A	3/4	ZTZ-0750-63-40-C	OBSOLETE	NONE
5970-00-809-1232	N/A	3/4	ZTZ-0750-63-40-B	OBSOLETE	NONE
5970-00-221-5369	N/A	3/4	ZTZ-0750-63-40-G	OBSOLETE	NONE
5970-01-335-7751	N/A	3/4	ZTZ-0750-74-20-B-OL-LTT	OBSOLETE	ZT99-16-078-3/4 (PFR-18)
5970-01-148-2387	N/A	3/4	ZTZ-0750-74-20-C	OBSOLETE	NONE
5970-01-093-3582	N/A	3/4	ZTZ-0750-SHN3-B	OBSOLETE	ZT02-17-022-3/4 (SH1+VNH-23)
5970-010-082-0299	ZT97-17-058-3/4	3/4	ZTZ-0750-SHX4-GP-20-B		
5970-01-091-4054	ZT97-17-066-3/4	3/4	ZTZ-0750-SHX4-63-20-B		
5970-01-267-0396	N/A	3/4	ZTZ-0750-SHX4-74-20-B-LTT	OBSOLETE	ZT97-17-092-3/4 (PFR-18)
5970-01-263-3948	N/A	3/4	ZTZ-0750-SH3-PFR-20-B	OBSOLETE	ZT02-17-014-3/4 (SH1+PFR-18)
4710-01-330-0085	ZT99-16-003-7/8	7/8	ZTZ-0875-GP-20-B		
5970-00-718-1944	N/A	7/8	ZTZ-0875-GP-20-G	OBSOLETE	NONE
5970-01-204-1168	ZT99-16-052-7/8	7/8	ZTZ-0875-63-20-B		
5970-01-013-6213	N/A	7/8	ZTZ-0875-63-40-C	OBSOLETE	NONE
5970-00-451-4942	N/A	7/8	ZTR-0875-63-40-C	OBSOLETE	NONE
5970-01-058-9344	N/A	7/8	ZTZ-0875-74-20-B	OBSOLETE	ZT99-16-039-7/8 (PFR-18)
5970-01-327-1154	N/A	7/8	ZTR-0875-74-20-B	OBSOLETE	NONE
5970-01-147-6118	N/A	7/8	ZTZ-0875-74-20-C	OBSOLETE	NONE
5970-01-261-2544	ZT99-16-039-7/8	7/8	ZTZ-0875-PFR-20-B	PFR-18	
5970-01-114-1976	N/A	7/8	ZTZ-0875-SHN3-B	OBSOLETE	ZT02-17-022-3/4 (SH1+VNH-23)
5970-01-144-5758	ZT97-17-066-7/8	7/8	ZTZ-0875-SHX4-63-20-B		

5970-01-285-3352	N/A	1.0	ZTM-1000-GP-40-B	OBSOLETE	NONE
5970-01-041-3881	ZT99-16-003-1.0	1.0	ZTZ-1000-GP-20-B		
5970-01-201-2714	ZT99-16-178-1.0	1.0	ZTZ-1000-ZRP-GP-20-B		
5970-00-478-0049	ZT99-16-052-1.0	1.0	ZTZ-1000-63-20-B		
5970-00-865-0369	N/A	1.0	ZTZ-1000-63-20-C	OBSOLETE	NONE
5970-00-221-5348	N/A	1.0	ZTZ-1000-63-40-G	OBSOLETE	NONE
5970-00-451-4941	N/A	1.0	ZTR-1000-63-40-C	OBSOLETE	NONE
5970-01-335-7753	N/A	1.0	ZTZ-1000-74-20-B-OL-LTT	OBSOLETE	ZT99-16-078-1.0 (PFR-18)
5970-01-147-6117	N/A	1.0	ZTZ-1000-74-20-C	OBSOLETE	NONE
5970-01-081-5128	N/A	1.0	ZTZ-1000-SHN3-B	OBSOLETE	ZT02-17-022-1.0 (SH1+VNH-23)
5970-01-006-1845	N/A	1.0	ZTZ-1000-SHX4-74-20-B	OBSOLETE	ZT97-17-092-1.0 (PFR-18)
5970-01-258-2242	N/A	1.0	ZTZ-1000-SHX4-74-20-B-LTT	OBSOLETE	ZT97-17-092-1.0 (PFR-18)
5970-01-263-5346	N/A	1.0	ZTZ-SH3-PFR-20-B	OBSOLETE	ZT02-17-014-1.0 (SH1+PFR-18)
5970-01-311-8844	ZT99-16-044-1-1/8	1-1/8	ZTZ-1125-GP-20-B-OL		
5970-01-201-3388	ZT99-16-052-1-1/8	1-1/8	ZTZ-1125-63-20-B		
5970-00-221-5383	N/A	1-1/8	ZTZ-1125-63-40-G	OBSOLETE	NONE
5970-01-243-6330	N/A	1-1/8	ZTZ-1125-74-20-B-OL	OBSOLETE	ZT99-16-078-1-1/8 (PFR-18)
5970-01-006-1846	N/A	1-1/8	ZTZ-1125-SHX4-74-20-B	OBSOLETE	ZT97-17-092-1-1/8 (PFR-18)
5970-01-320-4797	ZT99-16-044-1-1/4	1-1/4	ZTZ-1250-GP-20-B-OL		
5970-00-038-7469	ZT99-16-052-1-1/4	1-1/4	ZTZ-1250-63-20-B		
5970-00-865-0370	N/A	1-1/4	ZTZ-1250-63-20-C	OBSOLETE	NONE
5970-00-894-1027	N/A	1-1/4	ZTZ-1250-63-20-C-OL	OBSOLETE	NONE
5970-00-221-5370	N/A	1-1/4	ZTZ-1250-63-40-G	OBSOLETE	NONE
5970-01-332-1841	N/A	1-1/4	ZTZ-1250-74-20-B-OL-LTT	OBSOLETE	ZT99-16-078-1-1/4 (PFR-18)
5970-01-147-6119	N/A	1-1/4	ZTZ-1250-74-20-C	OBSOLETE	NONE
5970-00-438-4788	N/A	1-1/4	ZTZ-1250-SHN3-G	OBSOLETE	ZT02-17-022-1-1/4 (SH1+VNH-23-G)
5970-01-270-0175	N/A	1-1/4	ZTZ-1250-SHN3-B	OBSOLETE	ZT02-17-022-1-1/4 (SH1+VNH-23)
5970-01-146-0151	ZT97-17-066-1-1/4	1-1/4	ZTZ-1250-SHX4-63-20-B		
5970-01-006-1847	N/A	1-1/4	ZTZ-1250-SHX4-74-20-B	OBSOLETE	ZT97-17-092-1-1/4 (PFR-18)
5970-01-092-3522	N/A	1-3/8	ZTZ-1375-SHN3-B	OBSOLETE	ZT02-17-022-1-3/8 (SH1+VNH-23)
5970-01-200-7994	ZT99-16-052-1-1/2	1-1/2	ZTZ-1500-63-20-B		
5970-00-865-0371	N/A	1-1/2	ZTZ-1500-63-20-C	OBSOLETE	NONE
5970-00-195-1283	N/A	1-1/2	ZTZ-1500-63-40-B	OBSOLETE	NONE
5970-01-280-5369	N/A	1-1/2	ZTZ-1500-74-20-B-LTT	OBSOLETE	ZT99-16-078-1-1/2 (PFR-18)
5970-01-147-6121	N/A	1-1/2	ZTZ-1500-74-20-C	OBSOLETE	NONE
5970-00-821-6196	N/A	1-1/2	ZTZ-1500-74-20-C-OL	OBSOLETE	NONE

5970-01-133-5495	ZT97-17-066-1-1/2	1-1/2	ZTZ-1500-SHX4-63-20-B		
5970-01-201-2715	ZT99-16-052-1-3/4	1-3/4	ZTZ-1750-63-20-B		
5970-00-794-5800	N/A	1-3/4	ZTZ-1750-74-20-B	OBSOLETE	ZT99-16-039-1-3/4 (PFR-18)
5970-01-118-5103	ZT97-17-066-1-3/4	1-3/4	ZTZ-1750-SHX4-63-20-B		
5970-00-791-4310	N/A	1-7/8	ZTZ-1875-74-20-B	OBSOLETE	ZT99-16-039-1-7/8 (PFR-18)
5970-01-219-7342	ZT99-16-052-2.0	2.0	ZTZ-2000-63-20-B		
5970-01-047-4108	N/A	2.0	ZTZ-2000-63-20-C	OBSOLETE	NONE
5970-00-389-4453	ZT99-16-225-2.0	2.0	ZTZ-2000-ZRP-63-20-B		
5970-00-935-5059	N/A	2.0	ZTZ-2000-63-40-B	OBSOLETE	NONE
5970-01-092-3844	N/A	2.0	ZTZ-2000-SHN3-B	OBSOLETE	ZT02-17-022-2.0 (SH1+VNH-23)
5970-00-140-7166	ZT99-16-039-2.0	2.0	ZTZ-2000-PFR-18-B		
5970-00-791-4312	N/A	2-1/4	ZTZ-2250-74-20-B	OBSOLETE	ZT99-16-039-2-1/4 (PFR-18)
5970-00-791-4313	N/A	2-1/2	ZTZ-2500-74-20-B	OBSOLETE	ZT99-16-039-2-1/2 (PFR-18)
5970-01-285-3351	ZT99-16-033-2-5/8-B	2-5/8	ZTZ-2625-DVH-20-B		
5970-01-094-1610	N/A	3.0	ZTZ-3000-SHN3-B	OBSOLETE	ZT02-17-022-3.0 (SH1+VNH-23)
5970-00-791-4314	N/A	3.0	ZTZ-3000-74-20-B	OBSOLETE	ZT99-16-039-3.0 (PFR-18)
5970-00-221-5366	N/A	3-1/4	ZTZ-3250-ES-B	OBSOLETE	NONE
5970-00-376-0518	N/A	3-3/4	ZTZ-3750-ES-B	OBSOLETE	NONE
5970-00-177-6301	ZT99-16-052-3-7/8	3-7/8	ZTZ-3875-63-20-B		
5970-01-201-3387	ZT99-16-225-3-7/8	3-7/8	ZTZ-3875-ZRP-63-20-B		
5970-01-116-1889	N/A	3-7/8	ZTZ-3875-ZRP-63-20-C	OBSOLETE	NONE
5970-01-202-0289	N/A	4.0	ZTZ-4000-ZRP-63-40-G	OBSOLETE	NONE
5970-01-035-8955	ZT99-16-064-7.0-B	7.0	ZTZ-7000-VNH-B		
5999-01-416-4258	N/A		Z-5030-C	OBSOLETE	ZT02-15-005 (Z-6030)
5999-01-505-4745	ZT02-15-003-03		N/A	SHX4 Grounding Pad	
5999-01-505-4743	ZT02-15-003-01		N/A	SHX4 Grounding Pad	
5999-01-290-0592	ZT98-06-002		N/A	G.D. Dwg. # 6122943	
5975-01-470-3560	ZT98-12-008		N/A	Heartland	

8A-1195-LL-JFO-0582	ZT96-15-006		N/A	Z-5080-CN	
5970-01-508-5738	ZT98-04-016-#1		N/A	PRT-1	
5970-01-508-5746	ZT98-04-016-#2		N/A	PRT-2	
5970-01-508-5754	ZT98-04-016-#3		N/A	PRT-3	
5970-01-500-6558	ZT98-04-016-#4		N/A	PRT-4	
5970-01-500-6564	ZT98-04-016-#5		N/A	PRT-5	
5970-01-500-6563	ZT98-04-016-#6		N/A	PRT-6	
5970-01-508-5759	ZT98-04-016-#7		N/A	PRT-7	
5970-01-508-5762	ZT98-04-016-#8		N/A	PRT-8	
5970-01-508-8888	ZT98-04-016-#9		N/A	PRT-9	
5970-01-508-5980	ZT98-04-016-#10		N/A	PRT-10	
5970-01-508-5982	ZT98-04-016-#11		N/A	PRT-11	
5970-01-508-6893	ZT98-04-016-#12		N/A	PRT-12	
5970-01-508-5895	ZT98-04-016-#13		N/A	PRT-13	
5970-01-508-5896	ZT98-04-016-#14		N/A	PRT-14	